

List of remote control codes

TV		Ausind	0249	Clatronic	0243, 0249, 0259,	Durabrand	0077, 0097, 0133,
A.R. Systems	0274	Autovox	0249, 0257, 0259,		0260, 0261, 0262,		0225
Acme	0260		0260, 0328		0268, 0269, 0273,	Dux	0271
Acura	0261, 0273	Aventura	0097		0274, 0328	Dwin	0224
ADC	0259	Awa	0327, 0328	CMS	0327	Dynatron	0268, 0271, 0274
Admiral	0100, 0224, 0257,	Axion	0206	CMS Hightec	0328	Dynex	0181, 0182
	0258, 0259, 0264,	Baird	0328	Coby	0151	Elbe	0243, 0250, 0274,
	0265	Bang & Olufsen	0230, 0257	Colortyme	0072, 0090		0328
Advent	0204	Basic Line	0261, 0262, 0268,	Commercial Solutions		Elcit	0257
Adventura	0107		0273, 0274, 0328		0071	Electa	0270
Adyson	0260, 0327, 0328	Bastide	0260, 0328	Concerto	0072, 0090	ELECTRO TECH	0261
Agashi	0327, 0328	Baur	0271, 0274	Concorde	0261, 0273	Electroband	0057, 0101
Agazi	0259	Bazin	0328	Condor	0243, 0260, 0268,	Electrograph	0226
Aiko	0260, 0261, 0273,	Beko	0243, 0269, 0274,		0269, 0273, 0274,	Electrohome	0072, 0090, 0101,
	0274, 0327, 0328		0282, 0351, 0357,		0327		0102
			0372, 0380	Contec	0225, 0260, 0261,	Element	0180
Aim	0274	Belcor	0090		0266, 0273, 0327	Elin	0260, 0268, 0271,
Aiwa	0028, 0297	Bell & Howell	0065, 0100	Contec/Cony	0094, 0104		0273, 0274, 0327
Akai	0063, 0096, 0101,	Benq	0051, 0160, 0315	Continental Edison		Elite	0262, 0268, 0274
	0205, 0231, 0261,	Beon	0268, 0271, 0274		0267	Elman	0263
	0262, 0268, 0271,	Best	0243	Cosmel	0261, 0273	Elta	0261, 0273, 0327
	0273, 0274, 0327,	Bestar	0243, 0268, 0274	Craig	0104, 0225	Emerson	0065, 0072, 0077,
	0328	Binatone	0260, 0328	Crosley	0088, 0119, 0249,		0082, 0085, 0090,
Akiba	0262, 0274	Blue Sky	0262, 0274		0257		0094, 0095, 0097,
Akura	0259, 0262, 0273,	Blue Star	0270	Crown	0104, 0225, 0243,		0104, 0105, 0119,
	0274	Boots	0260, 0328		0249, 0261, 0268,		0225, 0243, 0257,
Alaron	0327	BPL	0270, 0274		0269, 0271, 0273,		0274
Alba	0243, 0260, 0261,	Bradford	0104, 0225		0274	Emprex	0200
	0262, 0266, 0269,	Brandt	0267, 0272	CS Electronics	0260, 0262, 0327	Envision	0072, 0090, 0096
	0271, 0273, 0274,	Brilliant	0228	CTC Clatronic	0263	Epson	0156, 0201, 0309
	0294, 0300, 0327	Brinkmann	0274	CTX	0159	Erres	0268, 0271, 0274
Albatron	0222	Brionvega	0257, 0268, 0271,	Curtis Mathes	0065, 0071, 0072,	ESA	0097
Alcyon	0249		0274		0085, 0088, 0090,	ESC	0328
Alleron	0105	Britannia	0260, 0327, 0328		0096, 0099, 0224	Etron	0261
Allorgan	0328	Brockwood	0090	CXC	0104, 0225	Eurofeel	0328
Allstar	0268, 0274	Broksonic	0063, 0225	Cybertron	0262	Euro-Feel	0259
America Action	0225	Bruns	0257	Cytron	0202	Euroline	0271
AMOi	0326	BTC	0262	Daewoo	0072, 0085, 0090,	Euroman	0243, 0327, 0328
Amplivision	0243, 0260, 0275,	Bush	0261, 0262, 0264,		0103, 0119, 0245,	Euromann	0259, 0260, 0268,
	0328		0266, 0268, 0270,		0260, 0261, 0268,		0274
Amstrad	0259, 0261, 0262,		0271, 0273, 0274,		0273, 0274, 0281,	Europhon	0260, 0263, 0268,
	0273, 0274		0282, 0286, 0294,		0285, 0303, 0321,		0274, 0327, 0328
Amtron	0104		0300, 0328, 0329,		0327, 0328, 0344,	Expert	0275
Anam	0225, 0261		0351, 0388, 0394,		0361, 0387	Exquisit	0274
Anam National	0102, 0104		0413	Dainichi	0262, 0327	Fenner	0261, 0273
Anglo	0261, 0273	Candle	0072, 0090, 0096,	Dansai	0259, 0268, 0271,	Ferguson	0267, 0271, 0272
Anitech	0249, 0259, 0261,		0107		0274, 0327, 0328	Fidelity	0260, 0264, 0274,
	0273, 0274	Capsonic	0259	Dantax	0243, 0271		0327
Ansonic	0243, 0250, 0261,	Carena	0274	Dawa	0274	Filsai	0328
	0263, 0273, 0274	Carnivale	0096	Daytron	0072, 0085, 0090,	Finlandia	0264
AOC	0072, 0090, 0096,	Carrefour	0266		0261, 0273	Finlux	0249, 0257, 0260,
	0103	Carver	0088	De Graaf	0264		0263, 0268, 0271,
Apex	0061, 0117, 0139	Cascade	0261, 0273, 0274	Decca	0260, 0268, 0271,		0274, 0328
Arcam	0327, 0328	Casio	0317		0274, 0328	FIRST LINE	0260, 0261, 0268
Arcam Delta	0260	Cathay	0268, 0271, 0274	Dell	0167, 0195	Firstline	0273, 0274, 0327,
Aristona	0268, 0271, 0274	CCE	0229, 0328	Denver	0308, 0312		0328
Arthur Martin	0275	Celebrity	0057, 0101	Desmet	0268, 0271, 0274	Fisher	0065, 0243, 0257,
ASA	0257, 0265	Celera	0117	Diamant	0274		0260, 0266, 0269,
Asberg	0249, 0268, 0274	Centurion	0268, 0271, 0274	Diamond	0327		0328
Astra	0261	Century	0257	DiamondVision	0213, 0221	Flint	0268, 0274
Asuka	0259, 0260, 0262,	CGE	0243, 0249	Dimensia	0099	Formenti	0249, 0257, 0258,
	0327, 0328	Changhong	0117	Disney	0137		0260, 0271, 0327
Atlantic	0260, 0268, 0271,	Chimei	0323	Dixi	0261, 0268, 0271,	Formenti/Phoenix	0327
	0274, 0327	Cimline	0261, 0273		0273, 0274, 0328	Fortress	0257, 0258
Atori	0261, 0273	Citizen	0072, 0085, 0090,	Dream Vision	0415, 0416	Fraba	0243, 0274
Auchan	0275		0096, 0104	DTS	0261, 0273	Friac	0243
Audiosonic	0243, 0260, 0261,	City	0261, 0273	Dual	0260, 0274, 0328	Frontech	0259, 0261, 0264,
	0262, 0268, 0271,	Clarion	0225	Dual-Tec	0260, 0261		0265, 0273, 0328
	0274, 0328	Clarivox	0271	Dumont	0076, 0090, 0108,	Fujitsu	0023, 0024, 0025,
AudioTon	0243, 0260, 0328				0257, 0260, 0263,		0105, 0328
Audiovox	0104, 0144, 0225				0328	Fujitsu General	0328

Fujitsu Siemens	0425, 0426, 0427, 0428, 0429	Hinari	0261, 0262, 0266, 0268, 0271, 0273, 0274	Kaisui	0260, 0261, 0262, 0270, 0273, 0274, 0327, 0328	Magnavox	0072, 0088, 0090, 0091, 0095, 0096, 0098, 0114, 0115, 0129, 0134, 0176, 0178, 0189, 0210
Funai	0033, 0034, 0035, 0036, 0037, 0097, 0104, 0105, 0225, 0259	Hisawa Hisense Hitachi	0262, 0270, 0275 0165 0006, 0014, 0015, 0016, 0042, 0072, 0090, 0094, 0173,	Kamosonic Kamp Kapsch Karcher	0260 0260, 0327 0265 0243, 0260, 0261, 0271, 0274	Magnum Majestic Mandor	0259, 0261 0100 0259
Futuretech	0104, 0225		0254, 0255, 0256, 0260, 0264, 0265, 0266, 0274, 0285, 0300, 0319, 0328, 0348, 0349, 0385, 0402, 0410	Kawasho	0072, 0090, 0101, 0327	Manesth	0259, 0260, 0268, 0271, 0274, 0328
Galaxi	0269, 0274		0402, 0410	KEC	0225	Marantz	0072, 0088, 0090, 0096, 0158, 0268, 0271, 0274
Galaxis	0243, 0274		0268, 0274	Kendo	0243, 0263, 0264, 0274		
Gateway	0163, 0226, 0227		0262	Kenwood	0072, 0090, 0096	Marelli	0257
GBC	0261, 0266, 0273	Hornophon	0262	KIC	0328	Mark	0268, 0271, 0273, 0274, 0327, 0328
GE	0069, 0071, 0072, 0073, 0077, 0090, 0099, 0102, 0106, 0112, 0131	Hoshai	0260, 0327	Kingsley	0260, 0327		
Geant Casino	0275	Huanyu	0260, 0327, 0328	KLH	0117	Masuda	0328
GEC	0260, 0265, 0268, 0271, 0274, 0328	Hygashi	0260, 0261, 0273, 0327, 0328	Kloss Novabeam	0104, 0107	Matsui	0260, 0261, 0264, 0266, 0268, 0271, 0273, 0274, 0328, 0405
Geloso	0261, 0264, 0273	Hyper	0259, 0260, 0268, 0270, 0271, 0274, 0275, 0328	Kneissel	0243, 0250, 0274		
General Technic	0261, 0273		0223	Kolster	0268, 0274		
Genexxa	0262, 0265, 0268, 0274	Hypson	0274	Koyoda	0261		
GFM	0177, 0210		0259, 0260, 0261, 0262, 0268, 0273, 0274	KTV	0085, 0096, 0104, 0225, 0229, 0260, 0328	Matsushita	0067
Giant	0328	Hyundai	0261, 0268, 0273, 0274			Maxent	0193, 0226
Gibraltar	0076, 0090, 0096, 0108	Iberia	0262, 0268, 0273, 0274	Korting	0243, 0257	Mediator	0268, 0271, 0274
GoldHand	0327	ICE	0262, 0268, 0273, 0274	Kosmos	0274	Medion	0259, 0261, 0274
Goldline	0274		0268, 0269, 0274	Koyoda	0261	Megapower	0222
GoldStar	0072, 0077, 0085, 0090, 0094, 0096, 0103, 0243, 0260, 0261, 0264, 0268, 0271, 0273, 0274, 0327, 0328	ICeS	0268, 0271, 0274	KTV	0085, 0096, 0104, 0225, 0229, 0260, 0328	Megatron	0072, 0077
		Ilo	0088	Kyoto	0327, 0328	MElectronic	0273, 0274, 0327, 0328
		IMA	0088	Lasat	0243	Melvox	0275
		Imperial	0168, 0277, 0313, 0397, 0430	Lenco	0261, 0273	Memorex	0065, 0072, 0077, 0100, 0103, 0133, 0219, 0261, 0273
		Indiana	0265	Lenoir	0260, 0261, 0273		
Goodmans	0164, 0259, 0261, 0266, 0268, 0271, 0273, 0274, 0322, 0328, 0395, 0399, 0412	Infinity	0265	Leyco	0259, 0268, 0271, 0274	Memphis	0261, 0273
		InFocus	0261, 0273	LG	0016, 0038, 0039, 0077, 0103, 0145, 0222, 0243, 0246, 0253, 0260, 0261, 0264, 0268, 0271, 0273, 0274, 0282, 0290, 0299, 0316, 0327, 0328, 0351, 0359, 0367, 0382, 0384, 0389, 0396	Mercury	0273, 0274
		Ingelen	0203			Metz	0257
		Ingersol	0249, 0260, 0261, 0262, 0268, 0271, 0273, 0274, 0328	LG/GoldStar	0246	MGA	0072, 0077, 0090, 0096, 0103
		Initial	0262, 0268, 0271, 0273, 0274, 0328	Liesenk	0271	Micromaxx	0259, 0261
Gorenje	0243, 0269	Inno Hit	0262, 0268, 0271, 0273, 0274, 0328	Liesenkotter	0274	Microstar	0259, 0261
GPM	0262		0259, 0261	Life	0259, 0261	Midland	0069, 0071, 0073, 0076, 0085, 0106, 0108
GPX	0211	Innovation	0182, 0188, 0190, 0209	Lifetec	0259, 0261, 0273, 0274		
Gradiente	0162		0076	Lloyds	0273	Minerva	0249
Graetz	0265	Insignia	0076	Loewe	0243, 0250, 0274, 0280, 0306, 0347	Minoka	0268, 0274
Granada	0249, 0260, 0264, 0266, 0268, 0271, 0274, 0275, 0328	Inteq	0243	Loewe Opta	0257, 0268, 0271	Mintek	0203
		Interactive	0261, 0273	Logik	0100	Mitsubishi	0006, 0015, 0016, 0048, 0072, 0077, 0090, 0103, 0196, 0224, 0257, 0266, 0268, 0274, 0298, 0371
Grandin	0261, 0262, 0270, 0271	Interbuy	0243, 0257, 0265, 0268, 0271, 0274	Luma	0264, 0271, 0273, 0274	Mivar	0243, 0249, 0250, 0260, 0327, 0328
Gronic	0328	Interfunk	0268, 0271, 0274	Lumatron	0264, 0268, 0271, 0274, 0328	Montgomery Ward	0100
Grundig	0242, 0243, 0249, 0274, 0356	International	0327	Liesenk	0271	Motorola	0102, 0224
Grunpy	0104, 0105, 0225	Intervision	0243, 0259, 0260, 0263, 0274, 0328	Liesenkotter	0274	MTC	0072, 0090, 0096, 0103, 0243, 0327
Haier	0187, 0207		0249, 0261, 0262, 0268, 0271, 0273, 0274	Life	0259, 0261	Multi System	0271
Halifax	0259, 0260, 0327, 0328	Irradio	0249, 0261, 0262, 0268, 0271, 0273, 0274	Lifetec	0259, 0261, 0273, 0274	Multitech	0104, 0225, 0229, 0243, 0260, 0261, 0263, 0264, 0266, 0271, 0273, 0274, 0327, 0328
Hallmark	0072, 0077, 0090		0262, 0274	Lloyds	0273		
Hampton	0260, 0327, 0328	Isukai	0260, 0328	Loewe	0243, 0250, 0274, 0280, 0306, 0347		
Hanseatic	0243, 0250, 0260, 0261, 0266, 0268, 0271, 0273, 0274, 0328	ITC	0260, 0328	Loewe Opta	0257, 0268, 0271		
		ITS	0262, 0268, 0270, 0274, 0327	Logik	0100		
		ITT	0261, 0265	Luma	0264, 0271, 0273, 0274		
Hantarex	0261, 0273, 0274	ITV	0261, 0271, 0274	Lumatron	0264, 0268, 0271, 0274, 0328		
Hantor	0274	Janeil	0107	Lux May	0268		
Harman/Kardon	0088	JBL	0088	Luxman	0072, 0090		
Harvard	0104, 0225	JC Penney	0072, 0073, 0085, 0090, 0099, 0103, 0106	Luxor	0260, 0264, 0328		
Harwood	0273, 0274		0072, 0073, 0085, 0090, 0099, 0103, 0106	LXI	0061, 0065, 0071, 0072, 0073, 0077, 0088, 0099		
Havermy	0224		0072, 0073, 0085, 0090, 0099, 0103, 0106	M Electronic	0260, 0261, 0265, 0267, 0268, 0271		
HCM	0259, 0260, 0261, 0270, 0273, 0274, 0328	JCB	0057, 0101	MAG	0050	Murphy	0260, 0327
		Jensen	0072, 0090	Magnadyne	0257, 0263, 0271	NAD	0061, 0072, 0077
		JVC	0017, 0018, 0019, 0092, 0093, 0094, 0106, 0251, 0252, 0266, 0268, 0293, 0360, 0379	Magnafon	0249, 0260, 0263, 0327	Naonis	0264
Hema	0273, 0328		0017, 0018, 0019, 0092, 0093, 0094, 0106, 0251, 0252, 0266, 0268, 0293, 0360, 0379			NEC	0026, 0053, 0072, 0090, 0096, 0102, 0103, 0266, 0328
Hewlett Packard	0146						
Higashi	0327						
HiLine	0274						

Neckermann	0243, 0257, 0260, 0264, 0268, 0269, 0271, 0274, 0328		0114, 0135, 0143, 0176, 0178, 0189, 0210, 0212, 0232, 0233, 0257, 0260, 0268, 0271, 0274, 0278, 0287, 0301, 0302, 0307, 0311, 0314, 0330, 0331, 0333, 0337, 0338, 0339, 0341, 0343, 0345, 0355, 0363, 0365, 0377, 0378, 0381, 0383, 0406, 0409, 0414	RCA	0071, 0072, 0073, 0074, 0075, 0090, 0099, 0102, 0103, 0109, 0120, 0179, 0218	SEI-Sinudyne	0257, 0263, 0265	
NEI	0268, 0271, 0274					Seleco	0264, 0265, 0266	
Net-TV	0226					Sencora	0261, 0273	
Neufunk	0273, 0274					Sentra	0273	
New Tech	0261, 0268				Realistic	Serino	0327	
New World	0262					Sharp	0009, 0010, 0011, 0072, 0080, 0081, 0082, 0083, 0085, 0090, 0094, 0110, 0148, 0183, 0216, 0224, 0247, 0248, 0258, 0266, 0288, 0304, 0324, 0325, 0340, 0358, 0362, 0369, 0386, 0392, 0398, 0400, 0401, 0403	
NewTech	0273, 0274, 0328				Recor			
Nicamagic	0260, 0327				Redstar			
Nikkai	0259, 0260, 0262, 0268, 0271, 0273, 0274, 0327, 0328				Reflex			
Nikko	0072, 0077, 0096				Revox	0243, 0268, 0271, 0274		
Nobliko	0249, 0260, 0263, 0327	Philips Magnavox	0089, 0114, 0115		Rex	0259, 0264, 0265		
Nokia	0265	Phoenix	0243, 0257, 0268, 0271, 0274, 0327		RFT	0243, 0250, 0257		
Norcent	0155				R-Line	0268, 0271, 0274		
Nordic	0328	Phonola	0257, 0268, 0271, 0274, 0327		Roadstar	0259, 0261, 0262, 0273	Sheng Chia	0224
Nordmende	0257, 0265, 0267, 0268	Pilot	0085, 0090, 0096		Robotron	0257	Shogun	0090
Nordvision	0271	Pioneer	0012, 0013, 0072, 0090, 0243, 0265, 0267, 0268, 0271, 0274, 0408		Rowa	0327, 0328	Siarem	0257, 0263, 0274
Novatronic	0274				Royal Lux	0243	Sierra	0268, 0274
Oceanic	0265, 0275				RTF	0257	Siesta	0243
Okano	0243, 0269, 0274	Plantron	0259, 0268, 0273, 0274		Runco	0076, 0096, 0108	Signature	0100
Olevia	0052, 0140, 0149, 0154, 0157				Saba	0257, 0265, 0267, 0272, 0376	Silva	0327
ONCEAS	0260	Playsonic	0328		Saisho	0259, 0260, 0261, 0273, 0328	Silver	0266
Onwa	0104, 0225	Polaroid	0117, 0152, 0184, 0220		Salora	0264, 0265	Singer	0257, 0263, 0275
Opera	0274	Poppy	0261, 0273		Sambers	0249, 0263	Sinudyne	0257, 0263, 0271, 0274
Oppo	0208	Portland	0072, 0085, 0090, 0103		Sampo	0072, 0085, 0090, 0096, 0226	Skantic	0265
Optimus	0065, 0067				Samsung	0029, 0030, 0031, 0032, 0044, 0045, 0046, 0047, 0072, 0077, 0084, 0085, 0086, 0087, 0090, 0094, 0096, 0103, 0118, 0217, 0229, 0235, 0236, 0237, 0243, 0259, 0260, 0261, 0268, 0269, 0271, 0273, 0274, 0284, 0295, 0327, 0328, 0336, 0346, 0390, 0407	Sonitron	0243, 0328
Optoma	0194	Prandoni-Prince	0149, 0264				Sonoko	0259, 0260, 0261, 0268, 0271, 0273, 0274, 0328
Optonica	0224	Precision	0260, 0328				Sonolor	0265, 0275
Orbit	0268, 0274	Prima	0161, 0207, 0261, 0265, 0273				Sontec	0243, 0268, 0271, 0274
Orion	0121, 0192, 0261, 0268, 0271, 0273, 0274, 0282, 0329	Princeton	0222				Sony	0041, 0057, 0058, 0059, 0060, 0101, 0116, 0125, 0126, 0127, 0142, 0169, 0170, 0171, 0172, 0174, 0234, 0261, 0266, 0276, 0289, 0292, 0393, 0411
Orline	0274	Prism	0069, 0106					
Osaki	0259, 0260, 0262, 0274, 0328	Profex	0261, 0273					
Oso	0262	Profi-Tronic	0268, 0274					
Otto Versand	0258, 0260, 0266, 0268, 0270, 0271, 0274, 0328	Proline	0268, 0274					
Pael	0260, 0327	Proscan	0071, 0073, 0099					
Palladium	0243, 0260, 0269, 0274, 0328	Prosonic	0243, 0260, 0271, 0274, 0327, 0328		Sandra	0260, 0327, 0328	Sound & Vision	0262, 0263
Palsonic	0328	Protech	0259, 0260, 0261, 0263, 0268, 0271, 0328		Sansui	0063, 0121, 0268, 0274	Soundesign	0072, 0077, 0090, 0104, 0105, 0225
Panama	0259, 0260, 0261, 0273, 0274, 0327, 0328	Proton	0072, 0077, 0090, 0094		Sanyo	0020, 0021, 0022, 0049, 0065, 0090, 0141, 0191, 0243, 0250, 0260, 0266, 0273, 0291, 0327, 0328, 0370, 0373, 0391	Soundwave	0268, 0271, 0274
Panasonic	0006, 0007, 0066, 0067, 0068, 0069, 0070, 0102, 0106, 0113, 0147, 0215, 0241, 0265, 0274, 0279, 0310, 0332, 0334, 0368, 0374	Protron	0150				Squareview	0097
		PROVIEW	0050, 0164				SSS	0090, 0104, 0225
		Provision	0271, 0274				Standard	0260, 0261, 0262, 0268, 0273, 0274, 0328
		Pulsar	0076, 0090, 0108					
		Pye	0268, 0271, 0274, 0296, 0338				Starlite	0104, 0225, 0271, 0273, 0274
		Pymi	0261, 0273	SBR	0271, 0274			
		Quandra Vision	0275	Sceptre	0166, 0185		Stenway	0270
		Quasar	0067, 0069, 0102, 0106	Schaub Lorenz	0265		Stern	0264, 0265
Panavision	0274	Quelle	0259, 0260, 0268, 0271, 0274, 0328	Schneider	0260, 0262, 0268, 0271, 0274, 0287, 0300, 0328, 0364, 0366		Strato	0273, 0274
Pathe Cinema	0243, 0250, 0260, 0275, 0327	Questa	0266				Stylandia	0328
Pausa	0261, 0273	Radialva	0274		Scotch	0072, 0077	Sunkai	0261
Penney	0061, 0069, 0071, 0077, 0096	RadioShack	0065, 0071, 0077, 0096, 0225, 0274		Scott	0072, 0077, 0090, 0094, 0104, 0105, 0199, 0225	Sunstar	0273, 0274
Perdio	0274, 0327	RadioShack/Realistic	0072, 0085, 0090, 0094, 0099, 0104				Sunwood	0261, 0268, 0273, 0274
Perfekt	0274						Superla	0260, 0327, 0328
Philco	0072, 0088, 0090, 0091, 0094, 0096, 0102, 0103, 0243, 0249, 0257, 0274	Radiola	0268, 0271, 0274, 0328		Sears	0061, 0065, 0071, 0072, 0073, 0077, 0088, 0090, 0097, 0099, 0105	Superscan	0095, 0224
		Radiomarelli	0257, 0274				SuperTech	0273, 0274, 0327
Philharmonic	0260, 0328	Radiotone	0243, 0268, 0273, 0274	SEG	0259, 0260, 0263, 0266, 0271, 0273, 0274, 0300, 0327, 0328		Supra	0261, 0273
Philips	0040, 0088, 0089, 0090, 0091, 0094, 0098, 0099, 0102,	Rank	0266				Supre-Macy	0107
							Supreme	0057, 0101
							Susumu	0262
							Sutron	0261, 0273
							SVA	0197
							Sydney	0260, 0327, 0328
				SEI	0274			

Sylvania	0072, 0088, 0089, 0090, 0091, 0095, 0096, 0097, 0098, 0175, 0177, 0210	Triumph	0274	Adventura	1023	Dumont	1072, 1078
		Uher	0243, 0249, 0265, 0268, 0274	Adyson	1090	Durabrand	1032
		Ultravox	0257, 0260, 0263, 0274, 0327	Aiwa	1023, 1072, 1073, 1074	Dynatech	1023
Symphonic	0097, 0104, 0108, 0133, 0210, 0225	Unic Line	0274	Akai	1071, 1073	Echostar	1064
Syntax	0149	United	0271	Akiba	1079, 1090	Elbe	1091
Syntax-Brilliant	0149	Universum	0243, 0249, 0259, 0268, 0269, 0271, 0274, 0328	Akura	1073, 1079, 1090	Elcatech	1090
Sysline	0271			Alba	1074, 1075, 1076, 1079, 1090, 1091	Electrohome	1021
Sytong	0327			Alienware	1066	Electroponic	1021
Tandy	0224, 0258, 0260, 0262, 0265, 0328	Univox	0274	Ambassador	1076	Elsay	1090
		Vector Research	0096	American High	1022	Elta	1079, 1090, 1091
Tashiko	0260, 0264, 0266, 0327, 0328	Vestel	0264, 0265, 0268, 0269, 0271, 0274, 0328	Amstrad	1072, 1090, 1091	Emerson	1021, 1022, 1023, 1070, 1090
				Anitech	1079, 1090	ESC	1075, 1091
Tatung	0102, 0227, 0260, 0268, 0271, 0274, 0328	Vexa	0261, 0271, 0273, 0274	Apex	1010	Etzuko	1079, 1090
				ASA	1077, 1078	Expressvu	1064
TCM	0259, 0261	Victor	0093, 0266, 0268	Asha	1020	Ferguson	1073
Teac	0274, 0328	VIDEOLOGIC	0327	Asuka	1072, 1077, 1078, 1079, 1090	Fidelity	1072, 1090
Tec	0260, 0261, 0273, 0328	Videologique	0260, 0262, 0327, 0328	Audio Dynamics	1018	Finlandia	1078
				Audiosonic	1091	Finlux	1072, 1073, 1078
Technics	0067, 0069, 0106	VideoSystem	0268, 0274	Audiovox	1021	Firstline	1074, 1077, 1079, 1090
TechniSat	0320, 0417, 0418, 0419	Videotechnic	0327, 0328	Baird	1072, 1073, 1075, 1091	Fisher	1019
		Vidikron	0088	Bang & Olufsen	1067	Flint	1074
Techwood	0069, 0072, 0090, 0106	Vidtech	0072, 0077, 0090, 0103	Basic Line	1074, 1075, 1076, 1079, 1090, 1091	Formenti/Phoenix	1078
TEDELEX	0328	Viewsonic	0153, 0186, 0226, 0318	Baur	1078	Frontech	1076
Teknika	0072, 0085, 0088, 0090, 0094, 0100, 0103, 0104, 0105, 0225	Viking	0107	Beaumarck	1020	Fuji	1022
		Viore	0198	Bell & Howell	1019	Fujitsu	1072
Teleavia	0267	Visiola	0260, 0327	Bestar	1075, 1076, 1091	Funai	1023, 1072
Telecor	0274, 0328	Vision	0268, 0274, 0328	Black Panther Line		Galaxy	1072
Telefunken	0267, 0268, 0272, 0274	Vizio	0090, 0136, 0160, 0227, 0420, 0421, 0422, 0423, 0424			Garrard	1023
						Gateway	1066
Telegazi	0274	Vortec	0268, 0271, 0274	Blaupunkt	1078	GBC	1076, 1079
Telemeister	0274	Voxson	0249, 0257, 0264, 0265, 0268, 0274	Bondstec	1076, 1090	GE	1020, 1022
Telesonic	0274			Broksonic	1054	GEC	1078
Telestarr	0274	Waltham	0260, 0274, 0328	Bush	1074, 1075, 1079, 1090, 1091, 1097, 1099, 1109, 1139	Geloso	1079
Teletech	0261, 0271, 0273, 0274	Wards	0072, 0077, 0088, 0090, 0091, 0096, 0098, 0099, 0100, 0103, 0105	Calix	1021	General	1076
				Candle	1020, 1021	General Technic	1074
Teleton	0260, 0328			Canon	1022	GOI	1064
Televideon	0327			Cathay	1091	GoldHand	1079, 1090
Televiso	0275	Watson	0268, 0271, 0274	Catron	1076	Goldstar	1018, 1021, 1072, 1077
Tensai	0261, 0262, 0268, 0273, 0274, 0328	Watt Radio	0260, 0263, 0327	CGE	1072, 1073	Goodmans	1072, 1075, 1076, 1091
		Waycon	0061	Cimline	1074, 1079, 1090	Gradiente	1023
Tesmet	0268	Wega	0257, 0266, 0274	CineVision	1058	Graetz	1073
Tevion	0259, 0261	Wegavox	0273	Citizen	1020, 1021	Granada	1078
Textet	0260, 0273, 0327, 0328	Weltblick	0268, 0271, 0274, 0328	Clatronic	1076, 1090	Grandin	1072, 1075, 1076, 1077, 1079, 1090, 1091
				Colortyme	1018	Grundig	1078, 1079
Thomson	0238, 0239, 0240, 0260, 0267, 0268, 0272, 0274, 0335	Westinghouse	0057, 0138, 0142	Condor	1075, 1076, 1091	Hanseatic	1077, 1078, 1091
		White Westinghouse	0008, 0119, 0260, 0263, 0271, 0274, 0327	Craig	1020, 1021	Harley Davidson	1023
Thorn	0271, 0274			Crown	1075, 1076, 1079, 1090, 1091	Harman/Kardon	1018
TMK	0072, 0077, 0090			Curtis Mathes	1018, 1020, 1022	Harwood	1090
TNCi	0076	Wincom	0055, 0056	Cybernex	1020	HCM	1079, 1090
Tokai	0268, 0274, 0328	Xrypton	0274	CyberPower	1066	Headquarter	1019
Tokyo	0260, 0327	Yamaha	0000, 0001, 0002, 0003, 0004, 0005, 0072, 0090, 0096, 0103	Daewoo	1023, 1075, 1076, 1091, 1116, 1141	Hewlett Packard	1066
Tomashi	0270			Dansai	1079, 1090, 1091	Hinari	1074, 1079, 1090, 1091
Toshiba	0027, 0043, 0053, 0054, 0061, 0062, 0063, 0064, 0065, 0122, 0123, 0124, 0128, 0130, 0132, 0139, 0214, 0244, 0266, 0283, 0305, 0328, 0329, 0342, 0350, 0352, 0353, 0354, 0375, 0404	Yamishi	0274, 0328	Daytron	1075, 1091	Hisawa	1074
		Yokan	0274	DBX	1018	Hitachi	1072, 1073, 1078, 1089, 1108, 1124
		Yoko	0243, 0259, 0260, 0261, 0262, 0268, 0271, 0273, 0274, 0327, 0328	De Graaf	1078	HNS	1060
				Decca	1072, 1073, 1078	Howard Computers	1066
				Dell	1066	HP	1066
				Denko	1090	HTS	1064
		Yorx	0262	DiamondVision	1050	Hughes	1035, 1040, 1061
		Zanussi	0264, 0328	DigiFusion	1092	Hughes Network Systems	1038, 1060
Totevision	0085	Zenith	0076, 0077, 0078, 0328	DIRECTV	1035, 1038, 1040, 1059, 1060, 1061, 1065	Humax	1035, 1060, 1094
Towada	0265, 0328			Dish Network	1064	Hush	1066
Trakton	0328			Dishpro	1064	Hypson	1074, 1079, 1090, 1091
Trans Continens	0274, 0328			Dual	1073, 1078, 1091		
Transtec	0327						
Trident	0328						
		VCR					
		ABS	1066				

iBUYPOWER	1066	Multitech	1020, 1023, 1072,	Ricavision	1066	Telefunken	1073
Impego	1076		1076, 1078, 1079,	Roadstar	1075, 1077, 1079,	Teletech	1090, 1091
Imperial	1072		1090		1090, 1091	Tenosal	1079, 1090
Inno Hit	1075, 1076, 1078,	Murphy	1072	Royal	1090	Tensai	1072, 1077, 1079,
	1079, 1090, 1091	NEC	1018, 1019, 1073	Runco	1032		1090
Innovation	1074	Neckermann	1073, 1078	Saba	1073	Tevion	1074
Instant Replay	1022	NEI	1078	Saisho	1074, 1079	Thomson	1073, 1087
Interbuy	1077, 1090	Nesco	1079, 1090	Samsung	1006, 1020, 1038,	Thorn	1073
Interfunk	1078	Nikkai	1076, 1090, 1091		1040, 1046, 1060,	Tivo	1035, 1036, 1037,
Intervision	1072, 1091	Nikko	1021		1080, 1107, 1110,		1039, 1040, 1060,
Irradio	1077, 1079, 1090	Niveus Media	1066		1112, 1121, 1123,		1061, 1062
ITT	1073	Noblex	1020		1140, 1142	TMK	1020
ITV	1075, 1077, 1091	Nokia	1073, 1091	Samurai	1076, 1090	Tokai	1077, 1079, 1090
JC Penney	1018, 1019, 1020,	Nordmende	1073	Sanky	1032	Tonsai	1079
	1021, 1022	Northgate	1066	Sansui	1033, 1056, 1069,	Toshiba	1004, 1005, 1034,
JCL	1022	Oceanic	1072, 1073		1073		1051, 1063, 1066,
JVC	1011, 1012, 1013,	Okano	1074, 1090, 1091	Sanyo	1019, 1020, 1114		1073, 1078, 1086,
	1014, 1015, 1016,	Olympus	1022	Saville	1091		1099, 1102, 1119,
	1017, 1018, 1019,	Optimus	1021	SBR	1078		1144
	1028, 1035, 1064,	Orion	1033, 1069, 1074,	Schaub Lorenz	1072, 1073	Totevision	1020, 1021
	1073, 1085, 1117,		1097, 1139	Schneider	1072, 1074, 1075,	Touch	1066
	1130, 1131, 1133,	Orson	1072		1076, 1077, 1078,	Towada	1079, 1090
	1134, 1135, 1136	Osaki	1072, 1077, 1079,		1079, 1090, 1091	Towika	1079, 1090
Kaisui	1079, 1090		1090	Sears	1019, 1021, 1022	TVA	1076
Karcher	1078	Otto Versand	1078	SEG	1079, 1090, 1091	Uher	1077
Kendo	1074, 1075, 1076,	Palladium	1073, 1077, 1079,	SEI-Sinudyne	1078	UltimateTV	1065
	1090		1090	Seleco	1073	Ultravox	1091
Kenwood	1018, 1019, 1073	Panasonic	1007, 1008, 1009,	Sentra	1076, 1090	Unitech	1020
Kodak	1021, 1022		1022, 1026, 1042,	Sentron	1079, 1090	United Quick Star	1075, 1091
Korpel	1079, 1090		1043, 1068, 1082,	Sharp	1031, 1045, 1057,	Universum	1072, 1077, 1078
Kyoto	1090		1101, 1126, 1132		1081, 1115, 1137	Vector Research	1018
Lenco	1075	Pathe Marconi	1073	Shintom	1079, 1090	Video Concepts	1018
Leyco	1079, 1090	Perdio	1072	Shivaki	1077	Videon	1074
LG	1021, 1053, 1072,	Philco	1022, 1090	Shogun	1020	Videosonic	1020
	1077, 1088, 1100,	Philips	1022, 1030, 1035,	Siemens	1077	Viewsonic	1066
	1106, 1125, 1143		1038, 1039, 1040,	Silva	1077	Voodoo	1066
Lifetec	1074		1044, 1055, 1060,	Silver	1091	Wards	1020, 1021, 1022,
Linksys	1066		1078, 1084, 1095,	Singer	1022		1023
Lloyd's	1023		1096, 1104, 1105,	Sinudyne	1078	Weltblick	1077
Loewe Opta	1077, 1078		1111, 1113, 1122,	Solavox	1076	XR-1000	1022, 1023
Logik	1079, 1090		1124, 1127, 1128,	Sonic Blue	1041, 1068	Yamaha	1018, 1019
Lumatron	1075, 1091		1129	Sonneclair	1090	Yamishi	1079, 1090
Luxor	1090	Philips Magnavox	1030	Sonoko	1075, 1091	Yokan	1079, 1090
LXI	1021	Phonola	1078	Sontec	1077	Yoko	1076, 1077, 1079,
M Electronic	1072	Pilot	1021	Sony	1000, 1001, 1002,		1090
Magnavox	1022, 1032, 1044,	Pioneer	1078, 1118		1003, 1024, 1027,	Zenith	1032
	1070	Polaroid	1010, 1049		1036, 1062, 1066,	ZT Group	1066
Magnin	1021	Portland	1075, 1076, 1091		1083, 1098, 1103,		
Manesth	1079, 1090	Prinz	1072		1138	DVD	
Marantz	1018, 1019, 1022,	Profex	1079	Stack	1066	4Kus	2097
	1078	Proline	1072	Stack 9	1066	Accurian	2220
Mark	1091	Proscan	1065	Standard	1075, 1091	Advent	2169, 2201
Marta	1021	Prosonic	1074, 1091	Stern	1091	AEG	2312
Matsui	1074, 1077	Pulsar	1032	STS	1022	Airis	2318
Matsushita	1022	Pye	1052, 1078	Sunkai	1074	Aiwa	2272
Media Center PC	1066	Quarter	1019	Sunstar	1072	Akai	2170, 2195, 2225,
Mediator	1078	Quartz	1019	Suntronic	1072		2227
Medion	1074	Quasar	1022	Sunwood	1079, 1090	Akura	2310
MEI	1022	Quelle	1072, 1078	Superscan	1070	Alba	2018, 2232, 2247,
Memorex	1019, 1020, 1021,	Radialva	1090	Sylvania	1022, 1023, 1044,		2259, 2264
	1022, 1023, 1032,	RadioShack	1021		1052, 1070	Alco	2199
	1048, 1069, 1072,	RadioShack/Realistic	1019, 1020, 1021,	Symphonic	1023, 1044, 1090	Alize	2315
	1077		1022, 1023	Systemax	1066	Allegro	2215
Memphis	1079, 1090			Tagar Systems	1066	Amittech	2312
MGN Technology	1020	Radiola	1078	Taisho	1074	Amphion MediaWorks	2145
Micromaxx	1074	Radix	1021	Tandberg	1091		
Microsoft	1066	Randex	1021	Tandy	1019	AMW	2145, 2313
Microstar	1074	RCA	1020, 1022, 1025,	Tashiko	1021, 1072	Apex	2044, 2045, 2046,
Migros	1072		1035, 1040, 1047,	Tatung	1072, 1073, 1078		2047, 2076, 2208,
Mind	1066		1060, 1065	TCM	1074, 1093, 1120		2209
Mitsubishi	1029, 1072, 1078	Realistic	1019, 1020, 1021,	Teac	1023, 1091	Apple	2163
Motorola	1022		1022, 1023	Tec	1076, 1090, 1091	Arrgo	2216
MTC	1020	ReplayTV	1041, 1068	Technics	1022	Asono	2318
		Rex	1073	Teknika	1021, 1022, 1023	Aspire	2140, 2202
		RFT	1076, 1078, 1090	Teleavia	1073	Astar	2162

V

ATACOM	2318	Enzer	2302	LG	2080, 2107, 2115,	2252, 2256, 2260,
Audiovox	2111, 2199	Epson	2165		2116, 2141, 2188,	2268, 2282, 2332,
Avious	2317	ESA	2219		2211, 2215, 2237,	2333, 2343, 2344,
Awa	2313	Finlux	2304, 2312, 2317		2239, 2285, 2293,	2345, 2367, 2371,
Axion	2171	Fintec	2299		2295, 2348, 2370	2373, 2380, 2382,
Bang & Olufsen	2210	Fisher	2212	Life	2228	2385
Baze	2317	Funai	2219	Lifetec	2228	Phonotrend
BBK	2318	Gateway	2097	Limit	2305	Pioneer
Bellagio	2313	GE	2079, 2206, 2209	Liquid Video	2204	2012, 2013, 2014,
Best Buy	2309	Gericom	2269	Liteon	2097, 2121, 2220	2063, 2064, 2065,
Blaupunkt	2209	GFM	2176	Loewe	2274	2066, 2067, 2113,
Blue Parade	2207	Giec	2300	LogicLab	2305	2134, 2207, 2230,
Boghe	2300	Global Solutions	2305	Magnavox	2075, 2096, 2178,	2236, 2265, 2266,
Brainwave	2312	Global Sphere	2305		2180, 2196, 2205,	2267, 2297, 2322,
Brandt	2198, 2238	Go Video	2135, 2215		2219, 2308	2351, 2352, 2353,
Broksonic	2192, 2195	Goodmans	2247, 2289, 2298,	Magnex	2317	2354, 2355, 2356,
Bush	2018, 2060, 2248,		2300, 2308, 2330,	Majestic	2314	2357, 2358, 2359,
	2264, 2301, 2308,		2369	Marantz	2282	2377
	2317, 2350, 2368	GPX	2177	Marquant	2312	Pointer
California Audio Labs		Gradiente	2197	Matsui	2198, 2296	2312
	2197	Graetz	2302	McIntosh	2149	Polaroid
Cambridge Audio	2304	Greenhill	2209	Mecotek	2312	Portland
CAT	2306, 2307	Grundig	2271	Medion	2228	Powerpoint
CAVS	2146	Grunkel	2312, 2316	Memorex	2078, 2184, 2195	Prima
Centrum	2307	GVG	2299	MiCO	2300, 2304	Proceed
CGV	2304, 2312	H&B	2308	Micromaxx	2228	Proscan
Changhong	2222	H_her	2318	Microsoft	2206	Prosonic
Cinetec	2313	Haaz	2304, 2305	Microstar	2228	2299, 2314
CineVision	2191, 2215	Haier	2172	Minoka	2312	Protron
Clatronic	2308, 2317	Harman/Kardon	2125, 2213	Minowa	2317	2152
Coby	2077, 2124, 2314	HiMAX	2309	Mintek	2167, 2209	Provision
Conia	2301	Hitachi	2008, 2033, 2108,	Mitsubishi	2081	2308
Continental Edison			2302, 2309, 2320,	Mizuda	2308, 2309	2308
	2313		2366	Monyka	2302	2194
Crown	2312	Hiteker	2208	Mustek	2232	Qwestar
C-Tech	2305	Home Tech Industries	2318	Mx Onda	2304	Raite
Curtis Mathes	2217		2316	Mystral	2316	2302
CVG	2299	Hyundai	2316	Naiko	2312	2058, 2059, 2071,
CyberHome	2048, 2068, 2216,	Ilo	2167	Nesa	2209	2079, 2183, 2199,
	2233, 2258	Initial	2167, 2209	Neufunk	2302	2206, 2207, 2209
Cytron	2166	Innovation	2228	Nevir	2312	RedStar
Daenyx	2313	Insignia	2080, 2175, 2219	Next Base	2221	2310, 2312, 2314
Daewoo	2083, 2215, 2280,	Integra	2207	Nexxtech	2161	Regent
	2299, 2312, 2313,	Irradio	2103	NU-TEC	2301	2203
	2326, 2376	iSymphony	2164	Onkyo	2205, 2290	Reoc
Daewoo International		JBL	2213	Oopla	2097	2305
	2313	JVC	2049, 2050, 2051,	Oppo	2150, 2173	Sabaki
Dalton	2311		2052, 2053, 2054,	Optim	2303	2305
Dansai	2303, 2312		2055, 2056, 2057,	Optimus	2230	2312
Daytek	2145, 2234, 2313		2070, 2242, 2261,	Orava	2308	2031, 2032, 2033,
Dayton	2313		2275, 2276, 2277,	Orbit	2313	2034, 2035, 2082,
DEC	2308		2278, 2339, 2340,	Orion	2027, 2060	2127, 2137, 2138,
Decca	2312		2341, 2342, 2386,	Oritron	2198, 2204	2154, 2182, 2197,
Denon	2105, 2147, 2197,		2387, 2389, 2390,	P&B	2308	2283, 2319, 2325,
	2286		2391	Pacific	2305	2346, 2347, 2349,
Denver	2288, 2308, 2310,	Jwin	2148	Panasonic	2015, 2016, 2017,	2372, 2381
	2314	Kansai	2314		2036, 2037, 2038,	Sansui
Denzel	2302	Kawasaki	2199		2039, 2040, 2041,	2027, 2195, 2304,
Desay	2159	Kennex	2312		2042, 2043, 2074,	2305, 2312
Diamond	2304, 2305	Kenwood	2123, 2197, 2270		2089, 2104, 2108,	2139, 2195, 2212,
DiamondVision	2179, 2186	KeyPlug	2312		2112, 2120, 2131,	2374
Disney	2078, 2088	Kiuro	2312		2132, 2197, 2205,	ScanMagic
DK Digital	2257	Kingavon	2308		2244, 2245, 2246,	2232
Dmtech	2226	Kiss	2302		2253, 2254, 2255,	Schaub Lorenz
Dual	2302	KLH	2199, 2209		2292, 2321, 2324,	2312
Durabrand	2218	Koda	2308		2327, 2328, 2329,	Schneider
DVX	2305	Koss	2095, 2198, 2204		2331, 2383, 2388	2226
Easy Home	2309	KXD	2309	Parasound	2151	Scientific Labs
Eclipse	2304	Landel	2221	peeKTON	2318	2305
E-Dem	2318	Lasonic	2214	Philips	2026, 2061, 2062,	2243, 2311
Electrohome	2312	Lawson	2305		2075, 2090, 2094,	Seeltech
Elin	2312	Lecson	2303		2096, 2097, 2103,	2318
Elta	2263, 2312, 2315	Lenco	2308, 2312, 2317		2110, 2126, 2180,	SEG
Emerson	2196, 2211, 2219	Lenoxx	2203, 2218		2193, 2205, 2231,	2240, 2302, 2305,
Enterprise	2211				2235, 2241, 2251,	2313
						Sharp
						2009, 2010, 2084,
						2122, 2142, 2143,
						2144, 2181, 2190,
						2228, 2262, 2375
						Shinsonic
						2167
						Sigmathek
						2309, 2318
						Silva
						2310
						Singer
						2304, 2305
						Skymaster
						2279, 2305

Viewmaster	3045	Condor	4074, 4090, 4137	Fuba	4074, 4083, 4090,	Lasat	4074, 4088, 4090,
Vision	3045	Connexions	4074, 4092		4092, 4093, 4101,		4100, 4133, 4134,
Visiopass	3051, 3054, 3055	Conrad	4074, 4133, 4136,		4133		4137
Vortex View	3045		4137	Galaxis	4074, 4087, 4090,	Lasonic	4062
Wittenberg	3048	Conrad Electronic	4137, 4139		4091, 4096, 4098,	Lenco	4074, 4083, 4099,
Zenith	3035, 3040, 3046	Contec	4096		4133, 4140		4133, 4137, 4139
Zentek	3044	Coolsat	4050	GE	4015, 4016, 4061,	Leng	4095
		Cosat	4098		4151	Lennox	4098
Sattelite		Coship	4063	General Instrument		Lenson	4136
AB Sat	4138, 4139	Crown	4089		4027, 4065	Lexus	4103
AccessHD	4058	Daeryung	4092	GMI	4089	LG	4053, 4057, 4099
ADB	4142	Daewoo	4107, 4139	GOI	4039	Lifesat	4074, 4090, 4134,
AGS	4138	DDC	4085	Goldbox	4135		4139
Akai	4101, 4103	Delega	4085	GoldStar	4099	Lifetec	4090
Alba	4083, 4084, 4085,	Dew	4096	Goodmans	4079, 4080, 4084	Lorenzen	4137
	4086, 4108, 4139	Diamond	4097	Goodmind	4061	Lorraine	4099
Aldes	4085, 4087, 4088	Digitality	4137	Grandin	4077	Lupus	4074, 4090
Allsat	4098, 4101, 4103	Digital Stream	4059	Grothusen	4083, 4099	Luxor	4136
Allsonic	4074, 4087, 4090	DIRECTV	4017, 4018, 4020,	Grundig	4084, 4086, 4093,	Lyonnaise	4102
Alltech	4139		4021, 4022, 4024,		4113, 4129, 4136,	Macab	4102
Alpha	4103		4037, 4038, 4040,		4140	Magnavox	4045, 4055
Alpha Digital	4058		4041, 4043, 4045,	Hänsel & Gretel	4137	Manata	4077, 4138, 4139
Alphastar	4031		4057, 4106, 4143,	Hantor	4083, 4095	Manhattan	4084, 4088, 4098,
Amitronica	4139		4144, 4145, 4146,	Hanuri	4088		4138
Amstrad	4089, 4113, 4136,		4147, 4148, 4149,	Hauppauge	4126	Marantz	4101
	4139		4150, 4151, 4152,	Heliocom	4137	Mascom	4088
Anglo	4139		4153, 4154, 4155,	Helium	4137	Maspro	4084, 4139
Ankaro	4074, 4087, 4090,		4156, 4157	Hinari	4085	Matsui	4138
	4139	Discoverer	4134	Hirschmann	4074, 4093, 4128,	Max	4137
Anttron	4083, 4086	Discovery	4138		4136, 4137, 4138	Mediabox	4135
Apollo	4083	Diseqc	4138	Hisawa	4095	Mediamarkt	4089
Armstrong	4089, 4103	Dish Network	4011, 4012, 4013,	Hisense	4066	Mediasat	4091, 4135, 4136
Artec	4054		4014, 4019, 4039,	Hitachi	4032, 4084, 4149,	Medion	4074, 4090, 4139
Asat	4101, 4103		4064		4153	Medison	4139
ASLF	4139	Dishpro	4039, 4064	Homecast	4005, 4006, 4007	Mega	4101, 4103
Astacom	4138	Distrisat	4103	Houston	4098	Memorex	4045
Astra	4089, 4091, 4100,	Ditristrad	4098	HTS	4039	Metronic	4077, 4078, 4083,
	4137, 4139	DNT	4092, 4101, 4103	Hughes	4018, 4022, 4144,		4086, 4087, 4088,
Astro	4074, 4086, 4088,	Drake	4026		4146, 4150, 4152		4139
	4090, 4093, 4135,	DStv	4140	Hughes Network Systems		Metz	4093
	4136, 4137	Dune	4074		4021	Micro electronic	4136, 4137, 4139
AudioTon	4086, 4098	EchoStar	4011, 4019, 4039,	Humax	4051, 4075, 4076,	Micro Technology	4139
Aurora	4140		4064, 4092, 4139		4110	MicroGem	4056
Austar	4140	Einhell	4083, 4087, 4089,	Huth	4087, 4089, 4094,	Micromaxx	4074, 4090
Axiel	4138		4136, 4139		4095, 4096, 4098,	Microstar	4090
Axis	4074, 4090, 4091,	Elap	4138, 4139		4137, 4141	Microtec	4139
	4096	Elekta	4088	Hypson	4077	Minerva	4093
Best	4074, 4090	Elsat	4139	Ilo	4066	Mitsubishi	4084, 4093, 4152
Blaupunkt	4093	Elta	4074, 4083, 4090,	Imex	4077	Mitsumi	4100
Blue Sky	4139		4098, 4101, 4103	Innovation	4090	Morgan's	4089, 4100, 4101,
Boca	4089, 4100, 4105,	Emanon	4083	Insignia	4057		4103, 4139
	4139	Emme Esse	4074, 4090	Intertronic	4089	Motorola	4008, 4009, 4010,
Boston	4138	Engel	4139	Intervision	4098, 4137		4065
Brain Wave	4095	Ep Sat	4084	ITT Nokia	4084	Multichoice	4140
Broadcast	4094	EURIEULT	4077	Jerrold	4065	Multitec	4134
Broco	4139	Eurodec	4102	Johansson	4095	Muratto	4099
BSkyB	4113, 4123	Europa	4103, 4136, 4137	JOK	4138	Mysat	4139
BT	4138	Europhon	4137	JSR	4098	Navex	4095
Bubu Sat	4139	Eurosat	4089	JVC	4011, 4019, 4039,	Neuhaus	4091, 4098, 4136,
Bush	4084, 4127	Eurosky	4074, 4089, 4090,		4079		4137, 4139
Cambridge	4136		4133, 4136, 4137	Kamm	4139	Neusat	4139
Canal Satellite	4135	Eurostar	4089, 4133, 4137	Kathrein	4093, 4101, 4103,	Next Level	4065
Canal+	4135	Eutelsat	4139		4109, 4112, 4120,	NextWave	4141
CaptiveWorks	4049	Exator	4083, 4086		4133, 4138, 4139	Nikko	4089, 4139
Channel Master	4060, 4085	Expressvu	4039	Kathrein Eurostar	4133	Nokia	4084, 4122
Chaparral	4025	Fenner	4074, 4134, 4139	Klap	4138	Nordmende	4083, 4084, 4085,
CHEROKEE	4138	Ferguson	4084, 4102, 4132	Konig	4137		4088, 4102
Chess	4134, 4139	Fidelity	4136	Kosmos	4099	Nova	4140
CityCom	4084, 4133, 4137	Finlandia	4084	KR	4086	Novis	4095
Clatronic	4095	Finlux	4084	Kreiselmeier	4093	Oceanic	4097
CNT	4088	FinnSat	4096, 4102	K-SAT	4139	Octagon	4083, 4086, 4096
Comag	4000, 4001, 4002,	Flair Mate	4139	Kyostar	4083	Okano	4089
	4003, 4004	Foxtel	4140	L&S Electronic	4074	Optex	4098
Commlink	4087	Freecom	4083, 4099, 4136			Optus	4135, 4140, 4141
Comtech	4096	FTEmaximal	4074, 4139				

Orbitech	4083, 4134, 4135, 4136	Satcom	4094, 4137	Tivax	4058
OSat	4086	Satec	4139	Tivo	4150
Otto Versand	4093	Satelco	4074	Tokai	4103
Pace	4084, 4093, 4113, 4121, 4125, 4138	Satford	4094	Tonna	4084, 4094, 4098, 4136, 4139
Pacific	4097	Satmaster	4094	Toshiba	4144, 4152, 4153
Packsat	4138	Satplus	4134	Triad	4099
Palcom	4085	Schneider	4090, 4134, 4138	Triasat	4136
Palladium	4089, 4136	Schwaiger	4097, 4134, 4137	Triax	4093, 4133, 4136, 4139
Palsat	4134, 4136	SCS	4133	Turnsat	4139
Panasat	4140	Seemann	4089, 4091, 4092	Tvonic	4132
Panasonic	4043, 4044, 4046, 4084, 4113, 4118, 4143, 4148	SEG	4074, 4083, 4090, 4095	Twinner	4077, 4139
Panda	4084, 4137	Seleco	4098	UEC	4140
Pansat	4047	Servi Sat	4077, 4139	Uher	4134
Patriot	4138	Siemens	4093	UltimateTV	4020
Paysat	4045	Silva	4099	Uniden	4029, 4045
PCT	4060	Skantin	4139	Unisat	4089, 4096, 4103
Philco	4055	Skardin	4091	Unitor	4095
Philips	4021, 4022, 4045, 4084, 4101, 4103, 4111, 4115, 4135, 4138, 4150, 4152, 4153, 4155, 4156	SKR	4139	Universum	4093, 4133, 4137
Phoenix	4096	Skymaster	4067, 4068, 4087, 4134, 4139	US Digital	4066
Phonotrend	4084, 4087, 4098	Skymax	4101, 4103	Variosat	4093
Pioneer	4124, 4135	SkySat	4134, 4136, 4137, 4139	Vega	4074
Polsat	4102	Skyvision	4098	Ventana	4101, 4103
Predki	4095	SM Electronic	4134, 4139	Viewsat	4048
Premiere	4098, 4135	Smart	4133, 4139	Visiosat	4095, 4098, 4138, 4139
Priesner	4089	Sony	4017, 4020, 4135	Voom	4065
Primestar	4030	SR	4089, 4100	Vortec	4083
Profile	4138	Star Choice	4065	Welltech	4134
Promax	4084	Starland	4139	WeTeKom	4134, 4136
Prosat	4085, 4087	Starring	4095	Wevasat	4084
Proscan	4015, 4016, 4040, 4151	Start Trak	4083	Wewa	4084
Protek	4097	Strong	4074, 4083, 4086, 4090, 4099, 4140	Winersat	4095
Proton	4066	STS	4033	Wisi	4084, 4092, 4093, 4136, 4137
Provision	4088	STVI	4077	Woorisat	4088
Quadral	4074, 4085, 4087, 4090, 4138	Sumida	4089	Worldsat	4138
Quelle	4093, 4133, 4137	Sunny Sound	4074	Xrypton	4074
Quiero	4102	Sunsat	4139	XSat	4139
RadioShack	4065	Sunstar	4074, 4089, 4100	Zehnder	4074, 4088, 4090, 4131, 4133
Radiola	4101, 4103	Supermax	4141	Zenith	4052, 4057, 4145
Radix	4092, 4119	Tandberg	4102	Zodiac	4086
Rainbow	4086	Tandy	4086		
RCA	4015, 4016, 4034, 4035, 4036, 4037, 4038, 4040, 4151, 4157	Tantec	4084	CD	
Realistic	4028	TCM	4090	Yamaha	5000, 5013
Redpoint	4091	Techniland	4094		
Redstar	4074, 4090	TechniSat	4071, 4072, 4073, 4092, 4103, 4116, 4117, 4134, 4135, 4136	CD Recoder	
RFT	4087, 4101, 4103	Technology	4140	Yamaha	5001
Roadstar	4139	Technosat	4141		
Roch	4077	Technowelt	4137	MD	
Rover	4074, 4139	Teco	4089, 4100	Yamaha	5002, 5003, 5004
Saba	4088, 4133, 4137, 4138	Telanor	4085		
Sabre	4084	Telasat	4133, 4137	Tape	
Sagem	4069, 4102	Telecom	4139	Yamaha	5005, 5006
Sakura	4096	Telefunken	4067, 4083, 4138		
Samsung	4018, 4021, 4023, 4041, 4042, 4081, 4082, 4083, 4114, 4150, 4154	Teleka	4086, 4089, 4092, 4136, 4137	Tuner	
SAT	4085, 4136	Telemaster	4088	Yamaha	5007, 5008, 5009, 5010, 5014, 5015, 5016, 5017, 5018
Sat Cruiser	4141	Telesat	4137		
Sat Partner	4083, 4086, 4088, 4095, 4099, 4136	Telestar	4134, 4135, 4136	USB	
Sat Team	4139	Televés	4084, 4136	Yamaha	5012, 5021
		Telewire	4098		
		Tempo	4141	DOCK	
		Tevion	4090, 4139	Yamaha	5011, 5022
		Thomson	4070, 4084, 4102, 4104, 4130, 4133, 4135, 4137, 4138, 4139		
		Thorens	4097	LD	
		Thorn	4084	Yamaha	2002